

| CODE | DESCRIPTION | TROUBLESHOOTING SOLUTION |
|------|-----------------------------|--|
| E01 | Table Leg Failure | Disconnect the leg cable from the cable attached to the desk. Reconnect and make sure the cables are fully connected. If error persists, contact VARIDESK. |
| E02 | Motor Overuse | If the desk is raised and lowered consistently for more than 2 minutes, it will display this error. Stop adjusting and resume after 20 minutes. |
| E03 | Overload | If the desk is at or over its weight capacity, remove items or reduce weight from desktop. Refer to instructions for maximum weight recommendation. |
| E04 | Data Error | The control panel may need to be reset. Follow initial setup instructions to reset the control panel. |
| E05 | Button Stuck | If one of the buttons on the control panel is stuck, move the affected button back and forth to release. If the button remains stuck, contact VARIDESK. |
| E06 | Connection Error | Check the connection between the desk and the control panel. Make sure all cables are fully connected. |
| E07 | Height Setting Error | Control panel error while registering desk height. Follow instructions to initialize and then recalibrate the desk. |